

Float HD Kit Installation (Model FHDCYL)

1. Remove accessories and tools from work surface.
2. Set Float to its highest position.
3. Use removable or mounted spring tension adjuster to set spring tension to “Min”.
4. Bring table forward and tip all the way over so top of work surface is on the floor. It is best to protect the surface so it does not get damaged.
5. Remove left foot when facing the front of the base/table. Front of the base has the Min/Max indicator facing the user. Four allen head screws attach the foot.
6. Install HD kit into the left leg. The kit is comprised of a mounting plate, two short flat head screws and a gas cylinder. The mounting plate is attached to the skinnier rod end of the gas cylinder. The larger diameter barrel end of the cylinder is inserted first into the leg. See images below.



8. Insert the gas cylinder all the way into the leg and line up the plate with 2 small threaded holes on the left leg. Secure the cylinder and plate in the left leg with the two small screw provided in the HD Kit.
9. Reassemble the left foot and stand table back to its upright position. Next re-install accessories and tools on to work surface. Float will be hard to lower if tools are not reinstalled before raising and lowering table.
13. Final step is to rebalance table with tension adjuster tool. Turning balance towards max line will make Float easier to go up.

available at:



800.531.3746

info@thehumansolution.com
thehumansolution.com