


Installation Manual


When using a Humanscale work surface with pre-drilled metal inserts

Parts Required


- A. (1) Float Table Base
- B. (2) Float Wing Brackets
- C. (2) Float Feet
- D. (1) Mounted or Removable Spring Tension Adjuster
- E. (1) Mounted Spring Tension Adjuster Plastic Housing
- F. (12) M6 Short Machine Screws
- G. (4) M5 Long Machine Screws
- H. (4) M6 Short Flat Head Machine Screws
- I. (8) M8 Long Machine Screws
- J. (4) M5 Short Machine Screws
- K. (1) Safety Leg Pin



Tools Required



Hardware Bag




Assembly Instructions for Humanscale pre-drilled work surfaces

1 Installing the Float Feet

- Turn the Float Base upside down so that the center beam is on the floor while the Float Feet are being installed
- Install the Feet by lining up each of the four holes over the top of the legs

Important: The longer section of the Feet must be on the same side as the spring tension min – max scale

- Use (4) M8 Long Machine Screws to secure each Foot to the Base frame (fig. D)




2 Installing the Float Wing Brackets

- Turn the Float base back up so that it rests on its feet
- There are two machine screws on each end of the center beam (fig. A)
Remove the lower screws on each end and set them aside


Warning: DO NOT UNSCREW THE UPPER SCREW AS IT WILL CAUSE MISALIGNMENT OF THE CENTER BEAM

Important: The machine screws are the ones on the same side as the spring tension min – max scale

- Using the machine screw removed in step 2b, install each Wing Bracket on its respective table side by screwing the machine screw through the Wing Bracket and back into the center beam (fig. B)
- Install the (4) M6 Short Flat Head Machine Screws through the top of the Wing Brackets and into the Float Base (fig. C)




3 Place the work surface face down on a soft surface to avoid scratching it



4 Turn the Float Base back upside down and place onto the underside of the work surface


- Ensure that all mounting holes on the Float Base line up with the pre-drilled metal inserts on the underside of the work surface
- With the Float Base in position, use the (12) M6 Short Machine Screws to secure the Float Base to the work surface (fig. E)



5 Installing the Release Paddle

- Line up the Release Paddle with the corresponding pre-drilled metal inserts on the underside of the work surface. If you have a right handed paddle, use the holes closer to the spring tension min - max scale. If you have a left hand paddle, use the holes on the opposite side.
- With the Release Paddle in position, use the (4) M5 Long Machine Screws to secure the Release Paddle to the work surface (fig. F)


Important: Do not over tighten the Release Paddle




6 Installing the Mounted Spring Tension Adjuster

(if you did not order your Float with this option, please proceed to step 7)


- Take the Mounted Spring Tension Adjuster and locate the metal shaft into the hex spigot on the center beam
- Line up the Mounted Spring Tension Adjuster with the corresponding pre-drilled metal inserts on the underside of the work surface
- With the Mounted Spring Tension Adjuster in position, use the (4) M5 Short Machine Screws to secure it to the work surface
- Take the Mounted Spring Tension Adjuster Plastic Housing, place and snap into position over the (4) M5 Short Machine Screws that were installed in step 6c (fig. G)



7 Carefully turn the Float back over and into position so that it is ready to use




8 Remove the Safety Leg Pin on the back left side by removing the tape and pulling it out (this is used for shipping purposes only) (fig. H)



9 You will now be able to operate your new Float by gently squeezing the Release Paddle and supporting the work surface as you raise and lower it

Adjusting Float

- 1 If you are finding it difficult to raise and lower your Float, please check the barrel adjuster behind the back of the Release Paddle (fig. A). The barrel adjuster needs to be adjusted to increase the tension in the Release Paddle which will allow for the Float to easily raise and lower. To make the required adjustment, simply turn the barrel adjuster counterclockwise until you have between $\frac{3}{4}$ " (20 mm) and $\frac{1}{2}$ " (12 mm) of metal thread showing. You will now find that the Release Paddle will engage better and allow for the Float to be raised and lowered





Important: Please be aware that your newly purchased Float will hold a maximum weight of 130 lbs. (60 kg) Please contact Customer Service if you would like to find out more information about our Float heavy duty kit that will increase the maximum weight loading from 130 lbs (60 kg) to 160 lbs (70 kg)

- 2 **Adding Weight to the Work Surface (fig. B)**

As you begin to add more weight to the work surface, it will become more difficult to raise and lower the table. The following steps explain how to adjust your Float to make it easier to raise and lower:

1. Squeeze the Release Paddle and raise the work surface to its maximum height (fully extended)
2. If using the Removable Spring Tension Adjuster, insert it into the hex spigot on the center beam to the right of the min – max scale
3. Using either the Removable or Mounted Spring Tension Adjuster, slowly begin to increase the tension by turning the Adjuster clockwise
4. You will start to see the red mark on the min – max scale move from the min mark towards the max mark
5. Once you have adjusted your Float, bring the work surface back down and try raising and lowering it a few times until it fluidly adjusts
6. If you need to make further adjustments, raise the Float to its maximum height and follow these steps again



Removing Weight from the Work Surface (fig. C)

As you begin to remove weight from your work surface, you will notice that Float will raise quickly and be difficult to lower. Simply follow the above instructions about adding weight to the work surface, but instead of turning the Adjuster clockwise, you will need to turn the Adjuster counterclockwise to release the spring tension in the Float.

- 3 Float sits on four glides which can be adjusted to level the work surface, if the floor is not level. These can be independently adjusted.

Troubleshooting Float


- 1 If you are finding it difficult to raise and lower your Float, please check the barrel adjuster behind the back of the Release Paddle (fig. A). The barrel adjuster needs to be adjusted to increase the tension in the Release Paddle which will allow for the Float to raise and lower. To make the required adjustment, simply turn the barrel adjuster counterclockwise until you have between $\frac{3}{4}$ " (20 mm) and $\frac{1}{2}$ " (12 mm) of metal thread showing. You will now find that the Release Paddle will engage better and allow for the Float to be raised and lowered
- 2 If your Float is adjusted so that the min – max mark is at the $\frac{3}{4}$ " position on the scale and the Float is still very difficult to raise and lower, please contact Customer Service who will help you order a heavy duty Float kit that will allow for the weight limit to be increased from 130 lbs (60 kg) to 160 lbs (70 kg) This heavy duty kit will make the table easier to adjust with the additional weight.

Installation Manual


When using your own work surface that is at least 3/4" thick and has no pre-drilled holes

Parts Required


- A. (1) Float Table Base
- B. (2) Float Wing Brackets
- C. (2) Float Feet
- D. (1) Mounted or Removable Spring Tension Adjuster
- E. (1) Mounted Spring Tension Adjuster Plastic Housing
- F. (12) 3/4" Wood Screws
- G. (4) 1 1/2" Wood Screws
- H. (4) M6 Short Flat Head Machine Screws
- I. (8) M8 Long Machine Screws
- J. (4) 1/2" Wood Screws
- K. (1) Safety Leg Pin



Tools Required




Extension Hex Drive



Pencil



5/32" (4 mm) Hex Bit



Ruler



3/16" (5 mm) Hex Bit




Power Drill



#2 Phillips Screwdriver

Hardware Bag




Assembly Instructions for work surfaces with no pre-drilled holes

1 Installing the Float Feet

- Turn the Float Base upside down so that the center beam is on the floor while the Float Feet are being installed
- Install the Feet by lining up each of the four holes over the top of the legs

Important: The longer section of the Feet must be on the same side as the spring tension min – max scale

- Use (4) M8 Long Machine Screws to secure each Foot to the Base frame (fig. D)




2 Installing the Float Wing Brackets

- Turn the Float base back up so that it rests on its feet
- There are two machine screws on each end of the center beam (fig. A).
Remove the lower screws on each end and set them aside

Warning: DO NOT UNSCREW THE UPPER SCREW AS IT WILL CAUSE MISALIGNMENT OF THE CENTER BEAM

Important: The machine screws are the ones on the same side as the spring tension min – max scale

- Using the machine screw removed in step 2b, install each Wing Bracket on its respective table side by screwing the machine screw through the Wing Bracket and back into the center beam (fig. B)
- Install the (4) M6 Short Flat Head Machine Screws through the top of the Wing Brackets and into the Float Base (fig. C)



3 Place the work surface face down on a soft surface to avoid scratching it

4 Turn the Float Base upside down (if it is not already) and place onto the underside of the work surface

- Please ensure that the Float Base is centered so that there is equal distance from the edge of the work surface on either side



For Float tables that have 30" (800 mm) deep surfaces:

Measure and mark 16.5" (420 mm) from the front edge of the work surface to the front edge of the center beam (the same edge that the spring min – max scale is positioned on) (example shown)

For Float tables that have 24" (600 mm) deep surfaces:



Measure and mark 13.5" (350 mm) from the front edge of the work surface to the front edge of the center beam (the same edge that the spring min – max scale is positioned on)

5 With the Float Base in position according to your markings, use the (12) 3/4" Wood Screws to secure the Float Base to the work surface. Use the smaller holes provided on the Float Base for this (fig. E)



6 Installing the Release Paddle

- Place the Float Release Paddle 1" (25 mm) from the front edge of the work surface and 2¼" from the inside edge of the Wing Bracket (fig. F)
*For mounting for left handed, use the same dimension measuring from the left side Wing Bracket
- Use the (4) 1½" (60 mm) Wood Screws to secure the Release Paddle to the work surface. (fig. G)




Important: Do not over tighten the Release Paddle


7 Installing the Mounted Spring Tension Adjuster

(if you did not order your Float with this option, please proceed to step 8)


- Take the Mounted Spring Tension Adjuster and locate the metal shaft into the hex spigot in the center beam
- Position the Mounted Spring Tension Adjuster in line with the installed Release Paddle. Use the (4) ½" Wood Screws to secure down to the work surface
- Take the Mounted Spring Tension Adjuster Plastic Housing, place and snap into position over the (4) ½" Wood Screws that were installed in step 7b (fig. H)



8 Carefully turn the Float back over and into position so that it is ready to use




9 Remove the Safety Leg Pin on the back left side by removing the tape and pulling it out (this is used for shipping purposes only) (fig. H)



10 You will now be able to operate your new Float by gently squeezing the Release Paddle and supporting the work surface as you raise and lower it

Adjusting Float

- 1 If you are finding it difficult to raise and lower your Float, please check the barrel adjuster behind the back of the Release Paddle (fig. A). The barrel adjuster needs to be adjusted to increase the tension in the Release Paddle which will allow for the Float to easily raise and lower. To make the required adjustment, simply turn the barrel adjuster counterclockwise until you have between $\frac{3}{4}$ " (20 mm) and $\frac{1}{2}$ " (12 mm) of metal thread showing. You will now find that the Release Paddle will engage better and allow for the Float to be raised and lowered





Important: Please be aware that your newly purchased Float will hold a maximum weight of 130 lbs. (60 kg) Please contact Customer Service if you would like to find out more information about our Float heavy duty kit that will increase the maximum weight loading from 130 lbs (60 kg) to 160 lbs (70 kg)

2 Adding Weight to the Work Surface (fig. B)

As you begin to add more weight to the work surface, it will become more difficult to raise and lower the table. The following steps explain how to adjust your Float to make it easier to raise and lower:

1. Squeeze the Release Paddle and raise the work surface to its maximum height (fully extended)
2. If using the Removable Spring Tension Adjuster, insert it into the hex spigot on the center beam to the right of the min – max scale
3. Using either the Removable or Mounted Spring Tension Adjuster, slowly begin to increase the tension by turning the Adjuster clockwise
4. You will start to see the red mark on the min – max scale move from the min mark towards the max mark
5. Once you have adjusted your Float, bring the work surface back down and try raising and lowering it a few times until it fluidly adjusts
6. If you need to make further adjustments, raise the Float to its maximum height and follow these steps again



Removing Weight from the Work Surface (fig. C)

As you begin to remove weight from your work surface, you will notice that Float will raise quickly and be difficult to lower. Simply follow the above instructions about adding weight to the work surface, but instead of turning the Adjuster clockwise, you will need to turn the Adjuster counterclockwise to release the spring tension in the Float.

- 3 Float sits on four glides which can be adjusted to level the work surface, if the floor is not level. These can be independently adjusted.

Troubleshooting Float

- 1 If you are finding it difficult to raise and lower your Float, please check the barrel adjuster behind the back of the Release Paddle (fig. A). The barrel adjuster needs to be adjusted to increase the tension in the Release Paddle which will allow for the Float to raise and lower. To make the required adjustment, simply turn the barrel adjuster counterclockwise until you have between $\frac{3}{4}$ " (20 mm) and $\frac{1}{2}$ " (12 mm) of metal thread showing. You will now find that the Release Paddle will engage better and allow for the Float to be raised and lowered
- 2 If your Float is adjusted so that the min – max mark is at the $\frac{3}{4}$ " position on the scale and the Float is still very difficult to raise and lower, please contact Customer Service who will help you order a heavy duty Float kit that will allow for the weight limit to be increased from 130 lbs (60 kg) to 160 lbs (70 kg) This heavy duty kit will make the table easier to adjust with the additional weight.