

ASSEMBLY INSTRUCTIONS LT BASE - MODEL 6049

NOTE: Please count and inspect all pieces before disposing of any carton or packing materials.

COMPONENTS: When ordering components, specific size information may be required.
Contact a Mayline Customer Service Representative. 1-800-822-8037


<u>REF.#</u>	QTY.	<u>DESCRIPTION</u>	PART No.
1	1	ACTUATOR ASSEMBLY	Z494
2	1	COLUMN BRACE ASSEMBLY	A7811
3	1	ANGLED BASE ASSEMBLY	A7810
4	1	CONTROL BOX, 2 LEG	Z537
5	1	MAIN CABLE	Z467
6	1	PLATE TOP MOUNTING	B9701


HARDWARE BAG (PART No. A7815) *For individual item, order by part number


<u>REF. #</u>	QTY.	DESCRIPTION	PART No.	
E1	1	3/8" CABLE CLAMP	F189	₽
E2	1	1/8" CABLE CLAMP	F690	
E3	4	GLIDE	Q607	U
E4	8	LOCK WASHER	W77	
E5	15	#10 x 3/4 PARTICLE BD. SCREW	X11	
E6	8	M8 x 16mm CAP SCREW	X432	
E7	2	#8 x 3/4 PARTICLE BD. SCREW	X5105	(a) (b)
E8	1	DPA SWITCH	Z458	
E9	2	#8 x 1 3/4" SCREW	X533	⊕ []######>
E10	6	1/4-20x5/8 PPHMS SCREW	X5112	()
E11	6	1/4-20 NUT, K-LOCK	T14	



800.531.3746 • info@thehumansolution.com • thehumansolution.com







INITIALIZATION of the system:

- 1. Your table is equipped with soft start / stop drive Actuator system. To properly function your unit must be initialized at set up.Check that all cord connections are completely installed into appropriate conection in Control Box.Plug Main Cable into power supply. Press down button and hold for 10 to 15 seconds. Note: Column may move up or down slightly while holding 'DN' button while system sets correct starting point.
- 2. Press 'UP' \(\sum \) button or 'DN' \(\sum \) button to obtain desired height.