# UPLIFT DESK® Modesty Panel
ACC009

Package Contents:

Modesty Panel
(available in five widths:
28.5'', 41.5'', 47.5'', 59.5'', and 71.5'')

Mounting clips
(qty 2 for all models, except
71.5'' which comes with three)

1/2'' Screws
(qty 2 for all models, except
71.5'' which comes with three)

ACC009~29 models only

Side-Mount Hardware Pack
contains hardware and instructions to
be used ONLY for the 28.5'' model when
mounting to the side of your UPLIFT Desk.

## Mounting on the back of your desk

Step 1
Place a plastic Mounting clip in the center of each exposed portion of the steel bar on the Modesty panel. Make sure the clips are facing IN. Make sure the wire management flap on the panel is facing the inside of the desktop so you can place your wires in the pouch.

Step 2
Center the modesty panel under the desktop about 1" from of the back edge*.

*NOTE: If you are clamping anything to the back edge of the desk, position the modesty panel more toward the front of the desk as needed.

Step 3
Once you decide on the placement, mark the location of the mounting clips and holes with a pencil mark. Depending on the material of your desktop surface, you may need to drill pilot holes. Use a drill with a 1/8" drill bit to make pilot holes **no deeper than** 1/2". Attach using the 1/2" screws and a Phillips head screwdriver.

CAUTION: If you have the 28.5'' model, Do NOT use the 1'' screws contained in the Side-Mount Hardware Pack.

Step 4
After the modesty panel is secured, undo the panel's Velcro and route your cables through the inside mesh pocket. When all cables are in place, use the Velcro to close the panel.

Mounting the 28.5'' model on the side of your desk

The 28.5'' wide Modesty panels have the option to be mounted to the *side* of your UPLIFT Desk.

If you choose to mount your 28.5'' model to the side of the desk, open the Side-Mount Hardware Pack and follow those instructions

⚠ **CAUTION:** Read all instructions before assembly. Failure to assemble properly may result in damage or personal injury.

UPLIFT DESK®

Modesty Panel Dimensions
ACC009

$\frac{7}{8}''$

28.5" model

15"

Center of holes are 8" from the edges.

28.5"

41.5" model

Center of holes are 11" from the edges.

41.5"

47.5" model

15"

Center of holes are 13" from the edges.

47.5"

59.5" model

15"

Center of holes are 20" from the edges.

59.5"

71.5" model

15"

Middle hole at 36"

Center of outer holes are approx 18" from the edges

71.5"