
e u To t e c h


ASSEMBLY INSTRUCTION


Remove all items from the carton . Verify all pieces before assembly.


PART LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	12	1	M6 Size Allen Wrench
2	1	Base	8	1	Backrest Post	13	1	Backrest Post Bellow
3	1	Seat Post	9	1	Backrest Screw (8*10mm)	14	2	Arm Bracket
4	1	Seat Post Cover	10	1	M5 Size Allen Wrench	15	2	Armrest
5	1	Mechanism	11	1	Backrest Bolt + Washers	16	2	Arm Width Adjustment
6	1	Seat			(10*25mm)			Knob + Washers












Ratchet Back Height Adjustment
To raise the back, slowly lift the back up until you hear a series of 4 to 5 clicks. Each click represents a position where the back will lock into place. To lower the back, raise the back all the way up until tension is released - the back will then return to the lowest position without stopping Raise back up to desired position.



- (A) Back angle adjustment lever.
- (B) Combination seat / back angle adjustment lever with infinite lock.
- (C) Seat height adjustment lever.
- (D) Forward tilt lever
 - *While seated, lift lever B and then lean back to activate locking mechanism;
 - *Pull lever D backward to allow seat to tilt forward- or -push lever D forward to straighten seat:
 - *To lock in desired position, push lever B downward.
- (E) Tension control knob-Turn colockwise to increase tension and counterclockwise to decrease tension.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
 DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
 DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHTENED
- EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OFTHE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS. DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY. NOTE:SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE
- ASSEMBLY INSTRUCTIONS.

