





FLEXMOUNT™ 8318


Installation Instructions

















PAGE 1 OF 2



FLEXMOUNT™ 8318


Parts List


ITEM	DESCRIPTION / PART NO.	QUANTITY
A	Mount Column 407602	1
B @0	Base Plate 8321	1
C O o o o o o o o o o o o o o o o o o o	Large "L" Bracket 702828	1
D eo	Small "L" Bracket 701116	1
E	Rectangular Spacer 701544	1
F	3/8-16 x 1-1/4 " Flat Socket Cap Scre 701855	ew 1
G	3/8-16 x 7/8" Flat Socket Cap Scr 701799	ew 1

ITEM	DESCRIPTION / PART NO.	QUANTITY
Н	3/8-16 Nylon Stop Nut 701418	1
	3/8-16 x 7/8" Button Socket Cap Scre 701122	w 1
1	3/8-16 x 2-1/2" Hex Head Bolt 700268	1
K	1/2-13 x 3" Socket Set Screw 701126	1
L	7/32" Allen Wrench 701127	1
M	3/32" Allen Wrench 700146	1



ILIFT[™] Installation Instructions








iLIFT™ Parts List

ITEM	DESCRIPTION / PART NO. QUANTITY
A	Spring-Assisted Monitor Tilter 1 407747
B	75/100mm VESA® Adapter Plate 1 105587
c	10-32 x 3/8" Phillips Flat Head Screw 1 702281 (4-pack)
D	M4 x 12mm Phillips Pan Head Screw 1 702096 (4-pack)
E	Dog Washer 1 105189
F	10-32 x 3/8 " FPhMS w/Lock Patch 1 705198



available at:



800.531.3746 info@thehumansolution.com thehumansolution.com