



UPLIFT DESK[®] Heavy Duty Locking Casters ACC035

Package Contents:




Heavy Duty Locking Caster



Step 1

Remove the caster or leveling stud that is currently on your desk. Before installing the Heavy Duty Locking Caster, lock it by pushing the large brake tab down, like shown.

Insert the Heavy Duty Locking Caster into the free hole left by the previous caster, and screw it counterclockwise to lock it into place. Repeat for all casters.



Step 2

Once all casters are secured to the feet, you can unlock them to roll your desk to a new location. You now have a mobile height adjustable desk that you can lock in place.

Heavy Duty Locking Casters rotate in multiple directions to allow for easy portability across a variety of floors and environments.



CAUTIONS & WARNINGS

⚠ CAUTION: Read all instructions before assembly. Failure to assemble properly may result in damage or personal injury.

⚠ WARNING: Exercise caution around the locking mechanism, it may lead to pinching or injuries.

© Copyright Notice: These instructions are a component of the Heavy Duty Locking Caster. These instructions are part of the scope of delivery, even if the item is resold. These instructions are also available on the UPLIFT Desk website: upliftdesk.com. Excerpts or copies may not be forwarded to third parties or used in any other published form without the prior written consent of UPLIFT Desk. These instructions are subject to United States copyright law.

© UPLIFT Desk • 1-800-349-3839 • info@upliftdesk.com • www.upliftdesk.com

ACC035/R02