


# UPLIFT DESK<sup>®</sup> Modesty Panel ACC009




UPLIFT Modesty Panels are available in five widths, 28.5, 41.5, 47.5, 59.5, and 71.5 inches. All panels are 15 inches high. (see reverse for dimensions)

**Package Contents:**

- UPLIFT Modesty Panel
- Mounting Clips\*
- Screws\*




\* for 28.5", 41.5", 47.5", and 59.5" models, qty 2 each  
for 71.5" model, qty 3 each.



## Step 1


Place a plastic mounting clip in the center of each exposed portion of the steel bar on the modesty panel. Make sure the wire management flap on the panel is facing the inside of the desktop so you can place your wires in the pouch.



## Step 2


Center the modesty panel under the desktop about 1" from of the back edge\*.

**\*NOTE:** If you are clamping anything to the back edge of the desk, position the modesty panel more toward the front of the desk as needed.



## Step 3

Once you decide on the placement, mark the location of the mounting clips and holes with a pencil mark. Depending on the material of your desktop surface, you may need to pre-drill the holes to allow for easier insertion of the mounting clips. Use a drill with a 1/8" drill bit to make pilot holes **no deeper than 1/2"**. Make sure the screw is not too long for your desktop thickness by holding the screw up next to the desktop's edge. Attach the mounting clips to the underside of the desk with the included screws and a Phillips head screwdriver.



## Step 4

After the modesty panel is secured, undo the panel's Velcro and route your cables through the inside mesh pocket. When all cables are in place, use the Velcro to close the panel.

**Copyright Notice:** These instructions are a component of the UPLIFT Modesty panel. These instructions are part of the scope of delivery, even if the item is resold. These instructions are also available on the UPLIFT Desk website: [upliftdesk.com](http://upliftdesk.com). Excerpts or copies may not be forwarded to third parties or used in any other published form without the prior written consent of UPLIFT Desk.

These instructions are subject to United States copyright law.