

# User's Manual

Wireless Newtral 2 Mouse

### TABLE OF CONTENTS

- I: Content
- II: Specifications
- III: Instructions
- IV: FAQ&Support
- V: Warranty Information

# I:CONTENT

- a: A Wireless Newtral 2 Mouse (with medium flange)
- b: A small flange and a large flange separately
- c: A battery
- d: A User's Manual

### II:SPECIFICATIONS

- \*Interface: 2.4 GHz Wireless
- \*Range: 32.8' (10 m)
- \*Warranty: 2 years
- \*Resolution: 1000.1500, 2000DPI
- \*Number of buttons: 6
- \*Compatibility:
- PC: Windows 8, Windows 7, Vista, 2000, XP
- Mac: Compatible Linux: Compatible

\*Detailed Specifications





# III:INSTRUCTIONS

One: The Newtral 2 mouse comes with Precision-Grip. Balance-Grip and Ergo-Grip for a fit and feel that's best for the way you work and







1. Precision-Grip: maximum precision for designing and gaming.

for maximum procision

\*Balance-Grip



2. Balance-Grip: Balance between precision and comfort.

Balance between precision and comfort



#### Q:Mouse not detected

A:Make sure the Newtral 2 Mouse is plugged into the correct port. Make sure to reboot your computer after you install the mouse driver.

Anchoring with your elbow to reduce

Two: The DPI button located on the top of the mouse is adjustable.

Press the DPI button and

then move the mouse to

find your preference.

# Q:You have trouble with precise positioning

IV:FAQ&SUPPORT

A:Using small flange for maximum precision.

Resolution: 1000-1500-2000

3. Ergo-Grip: Maximum comfort for office usage.

### Q:The cursor moves too slow or too fast

A:Adjust the DPI button located after the scrolling wheel to find the right speed for you.

## Q:The cursor doesn't move after some time without usage

A:The wireless version will sleep after a few minutes without usage to save battery power. Just click any button to wake it up.

#### Q:Cursor moving by itself

A:A reflective surface may cause cursor drift. Put the Newtral Mouse on a nonreflective mouse pad.

#### Q:There is no red light from the sensor located at the bottom as other optical mice

A: There is no red light coming out from the Newtral2 Ergonomic Optical Mouse. The new technology helps reduce light pollution.

# V:WARRANTY INFORMATION

Microtouch Technology Inc offers a two-year warranty on the Newtral 2 Mouse.

This Warranty is applicable to the initial purchaser only and is non-transferable.

We warrants that at the time of customer's receipt, the product will be in good working order and will be free from defects in material and workmanship.

This Warranty does not apply to normal wear and tear or damage caused by accident, neglect, misuse or improper installation or operation.

We will not be responsible for damage due to service, maintenance, modifications or tampering by anyone other than our authorized representative.

Within the Warranty period, we will either repair or replace the defective product.

This Warranty does not cover damage caused by a carrier or transportation of the product from one location to another, or alterations made by owner.



800.531.3746 • info@thehumansolution.com • thehumansolution.com

NEWTRAL 2 ERGOMOMIC MOUSE

# **USER'S MANUAL**



