UPLIFT DESK® Spacer for CPU Holder

Package Contents:




Small spacer (qty 1) 5/16" Machine screws (qty 8)






1/2" Machine screws (qty 2)



Step 1

Using six (6) 5/16" Machine screws, attach the Track to the Small and Large spacers as shown.

Note: There are two lengths of screws: 5/16" are the shorter ones, and 1/2" are longer. Do not use interchangeably.



8

₿

C

fig 2

Step 2

Place the assembly over the center rails or crossbar ends. Mark screw locations. (If pre-drilling, use 1/8" diameter drill bit and drill 1/2" deep) Then attach to desktop using eight (8) 5/8" Wood screws.

Note-


When placing the assembly over the crossbar end, you can have it pointing in either direction. If you want your CPU to be positioned closer to the back of the desk, attach the assembly with the Large spacer behind the crossbar end (see fig. 1). If you'd prefer your CPU to be closer to the front of the desk, mount the assembly with the Large spacer in front of the crossbar end (see fig. 2).

Step 3

Attach the Back bumper to the rear side of the assembly. Use one (1) 1/2" Machine screw in the center hole.



Slide the CPU holder onto the Track.



Step 5

Attach the Track guard to prevent the CPU from sliding off. Use two (2) 5/16" Machine screws on the right and left holes, and one (1) 1/2" Machine screw in the center hole.

Copyright Notice: These instructions are a component of the UPLIFT Spacer. These instructions are part of the scope of delivery, even if the item is resold. These instructions are also available on the UPLIFT Desk website: upliftdesk.com. Excerpts or copies may not be forwarded to third parties or used in any other published form without the prior written consent of UPLIFT Desk.

These instructions are subject to United States copyright law.