


Under Desk Hammock

ACC042

UPLIFT DESK

Package Contents




IMPORTANT NOTE

Body weight limit to use hammock when attached to desk is 200 lbs or less. Your body weight AND the combined weight of your desktop plus all of the items on your desk must be factored in. The Hammock has a weight capacity of 400 lbs, but the lifting capacity for a 2-leg frame is 355 lbs.

NOTE: This was designed to be used only on two and three leg UPLIFT Desk V2 Standard frames, 72" wide or wider. It will not work in conjunction with V1 model UPLIFT Desks or the UPLIFT Desk V2 Commercial frames.

Only for use on UPLIFT Desk V2 Standard Frames. Other brand desks do not support the weight properly and could cause injury.



Step 1

Under your desktop are mounting points to attach accessories. Starting at the outer most holes on both left and right sides, attach the Anchor Plates that came with your UPLIFT Desk to your frame.

Refer to the instructions provided with your UPLIFT Desk frame for complete frame assembly.



Step 2

Unpack and unroll your Hammock, and attach one Carabiner to each side of the frame at the large hole on the Anchor Plates.




Step 3

You may find that it is easier to get into the Hammock when the desk is completely lowered, and the Hammock is resting on the floor. To enter the Hammock, ensure that you weigh 200 lbs or less then shimmy under the desk and lay down inside the pocket of the Hammock. If you're alone, lay with your head toward the keypad so you can reach it. Otherwise, we advise having a friend help you raise the desk safely. Once in the Hammock, raise the desk to a height where you are comfortable.

Alternately:

You may prefer to raise the desk to the preferred height first, and enter the Hammock that way. To do this, lean over and back yourself under the desk, holding firmly onto the edge closest to you as you sit down carefully in the center of the Hammock. Holding onto both the right and left sides of the Hammock, rotate your body inside and get comfortable!

NOTE: If you want to leave the desk up when getting in or out, TAKE SPECIAL CARE to avoid falling as you exit.






Further use: Outdoor Hammock Use.

The extra Ropes included in this package are not for use with your UPLIFT Desk, but are provided should you desire to use your Hammock outdoors.

Ropes can be used to secure your Hammock to two weight-bearing posts or strong trees. Make sure you know your knots before you attempt to tie your Hammock to any location.

CAUTIONS & WARNINGS

- ⚠ **CAUTION:** Read all instructions before assembly. Failure to assemble or operate properly may result in damage or personal injury. Retain manual for future reference.
- ⚠ **WARNING:** Only for use on UPLIFT Desk V2 Standard Frames. Other brand desks do not support the weight properly and could cause injury.
- ⚠ **WARNING:** Body weight limit to use hammock when attached to desk is 200 lbs or less. Your body weight AND the combined weight of your desktop plus all of the items on your desk must be factored in. The Hammock has a weight capacity of 400 lbs, but the lifting capacity for a 2-leg frame is 355 lbs.
- ⚠ **WARNING:** Do not swing Hammock while lying in it, as this can cause the desk to tip over.
- ⚠ **WARNING:** Hammock is intended to be used by one person at a time.

 **Copyright Notice:** These instructions are a component of this accessory. These instructions are part of the scope of delivery, even if the item is resold. These instructions are also available on the UPLIFT Desk website: uplift-desk.com. Excerpts or copies may not be forwarded to third parties or used in any other published form without the prior written consent of UPLIFT Desk. These instructions are subject to United States copyright law.